

Sport Visor Fitting Template

1

PRINT OUT TEMPLATE ENSURING TO SET PRINTER TO "SCALE - ACTUAL SIZE".

2

CUT OUT THE VISOR TEMPLATE (OUTSIDE OF THE BLUE OUTLINE.).

3



PLACE ON THE VISOR WHERE REQUIRED TO CHECK THE FIT OF THE HEATED INSERT.

4


IF THE TEMPLATE FITS, HEAD OVER TO WWW.HEATEDVISOR.CO.UK AND PURCHASE YOUR HEATED VISOR.



TO BE PRINTED ON A4

	Sport Visor Fitting Template
	 Cut out-side the line, Template perimeter

Enduro Visor Fitting Template



1

PRINT OUT TEMPLATE ENSURING TO SET PRINTER TO "SCALE - ACTUAL SIZE".

2

CUT OUT THE VISOR TEMPLATE (OUTSIDE OF THE BLUE OUTLINE.).



3

PLACE ON THE VISOR WHERE REQUIRED TO CHECK THE FIT OF THE HEATED INSERT.


4

IF THE TEMPLATE FITS, HEAD OVER TO WWW.HEATEDVISOR.CO.UK AND PURCHASE YOUR HEATED VISOR.

TO BE PRINTED ON A4

	Enduro Visor Fitting Template
	 Cut out-side the line, Template perimeter

Shoei 001 Visor Fitting Template



1

PRINT OUT TEMPLATE ENSURING TO SET PRINTER TO "SCALE - ACTUAL SIZE".

2

CUT OUT THE VISOR TEMPLATE (OUTSIDE OF THE BLUE OUTLINE).

3

PLACE ON THE VISOR WHERE REQUIRED TO CHECK THE FIT OF THE HEATED INSERT.


4

IF THE TEMPLATE FITS, HEAD OVER TO WWW.HEATEDVISOR.CO.UK AND PURCHASE YOUR HEATED VISOR.

TO BE PRINTED ON A4

	Shoei 001 Fitting Template
	 Cut out-side the line, Template perimeter


Schuberth 002 Visor Fitting Template



TO BE PRINTED ON A3

	Schuberth 002 Visor Fitting Template
	 Cut out-side the line, Template perimeter

Arai 003 Visor Fitting Template





1
PRINT OUT TEMPLATE
ENSURING TO SET
PRINTER TO "SCALE -
ACTUAL SIZE".

2
CUT OUT THE VISOR
TEMPLATE (OUTSIDE OF
THE BLUE OUTLINE.).

3
PLACE ON THE VISOR
WHERE REQUIRED TO
CHECK THE FIT OF THE
HEATED INSERT.

4
IF THE TEMPLATE FITS,
HEAD OVER TO
WWW.HEATEDVISOR.CO.UK
AND PURCHASE YOUR
HEATED VISOR.

TO BE PRINTED ON A4

	Arai 003 Fitting Template
	 Cut out-side the line, Template perimeter

Shoei 004 Visor Fitting Template

1

PRINT OUT TEMPLATE
ENSURING TO SET
PRINTER TO "SCALE -
ACTUAL SIZE".

2

CUT OUT THE VISOR
TEMPLATE (OUTSIDE OF
THE BLUE OUTLINE.).

3

PLACE ON THE VISOR
WHERE REQUIRED TO
CHECK THE FIT OF THE
HEATED INSERT.

4


IF THE TEMPLATE FITS,
HEAD OVER TO
WWW.HEATEDVISOR.CO.UK
AND PURCHASE YOUR
HEATED VISOR.



TO BE PRINTED ON A4

	Shoei 004 Fitting Template
	 Cut out-side the line, Template perimeter

Arai 006 Fitting Template





1
PRINT OUT TEMPLATE
ENSURING TO SET
PRINTER TO SET
ACTUAL SIZE". "SCALE -

2
CUT OUT THE VISOR
TEMPLATE (OUTSIDE OF
THE BLUE OUTLINE.).


3
PLACE ON THE VISOR
WHERE REQUIRED TO
CHECK THE FIT OF THE
HEATED INSERT.

4
IF THE TEMPLATE FITS,
HEAD OVER TO
WWW.HEATEDVISOR.CO.UK
AND PURCHASE YOUR
HEATED VISOR.

TO BE PRINTED ON A4

	Arai 006 Fitting Template
	Cut out-side the line, Template perimeter

Klim 007 Visor Fitting Template



1

PRINT OUT TEMPLATE ENSURING TO SET PRINTER TO "SCALE - ACTUAL SIZE".

2

CUT OUT THE VISOR TEMPLATE (OUTSIDE OF THE BLUE OUTLINE.).

3



PLACE ON THE VISOR WHERE REQUIRED TO CHECK THE FIT OF THE HEATED INSERT.

4

IF THE TEMPLATE FITS, HEAD OVER TO WWW.HEATEDVISOR.CO.UK AND PURCHASE YOUR HEATED VISOR.



TO BE PRINTED ON A4

	Klim 007 Visor Fitting Template
	 Cut out-side the line, Template perimeter