

Arai 005 Fitting Template

1
PRINT OUT TEMPLATE TO SET
ENSURING TO "SCALE"
PRINTER TO "SCALE".
ACTUAL SIZE".

2
CUT OUT THE VISOR
TEMPLATE (OUTSIDE OF
THE BLUE OUTLINE).

3
PLACE ON THE VISOR
WHERE REQUIRED TO
CHECK THE FIT OF THE
HEATED INSERT.

4
IF THE TEMPLATE FITS,
HEAD OVER TO
WWW.HEATEDVISOR.CO.UK
AND PURCHASE YOUR
HEATED VISOR.

TO BE PRINTED ON A4



Arai 005 Fitting Template

Cut out-side the line, Template perimeter