



Sport Visor Fitting Template



TO BE PRINTED ON A4

	Sport Visor Fitting Template
	 Cut out-side the line, Template perimeter

Shoei 001 Visor Fitting Template



1

PRINT OUT TEMPLATE
ENSURING TO SET
PRINTER TO "SCALE -
ACTUAL SIZE".

2

CUT OUT THE VISOR
TEMPLATE (OUTSIDE OF
THE BLUE OUTLINE.).

3

PLACE ON THE VISOR
WHERE REQUIRED TO
CHECK THE FIT OF THE
HEATED INSERT.

4

IF THE TEMPLATE FITS,
HEAD OVER TO
WWW.HEATEDVISOR.CO.UK
AND PURCHASE YOUR
HEATED VISOR.

TO BE PRINTED ON A4




Shoei 001 Fitting Template



Cut out-side the line, Template perimeter


Arai 005 Fitting Template



TO BE PRINTED ON A4

	Arai 005 Fitting Template
	Cut out-side the line, Template perimeter


Schuberth 002 Visor Fitting Template



TO BE PRINTED ON A3

	Schuberth 002 Visor Fitting Template
	 Cut out-side the line, Template perimeter

Enduro Visor Fitting Template



1

PRINT OUT TEMPLATE
ENSURING TO SET
PRINTER TO "SCALE -
ACTUAL SIZE".

2

CUT OUT THE VISOR
TEMPLATE (OUTSIDE OF
THE BLUE OUTLINE.).

3

PLACE ON THE VISOR
WHERE REQUIRED TO
CHECK THE FIT OF THE
HEATED INSERT.


4

IF THE TEMPLATE FITS,
HEAD OVER TO
WWW.HEATEDVISOR.CO.UK
AND PURCHASE YOUR
HEATED VISOR.

TO BE PRINTED ON A4

	Enduro Visor Fitting Template
	 Cut out-side the line, Template perimeter


Arai 003 Visor Fitting Template



TO BE PRINTED ON A4

	Arai 003 Fitting Template
	 Cut out-side the line, Template perimeter

Klim 007 Visor Fitting Template



TO BE PRINTED ON A4

	Klim 007 Visor Fitting Template
	 Cut out-side the line, Template perimeter

Shoei 004 Visor Fitting Template

1

PRINT OUT TEMPLATE
ENSURING TO SET
PRINTER TO "SCALE -
ACTUAL SIZE".

2

CUT OUT THE VISOR
TEMPLATE (OUTSIDE OF
THE BLUE OUTLINE.).

3

PLACE ON THE VISOR
WHERE REQUIRED TO
CHECK THE FIT OF THE
HEATED INSERT.

4

IF THE TEMPLATE FITS,
HEAD OVER TO
WWW.HEATEDVISOR.CO.UK
AND PURCHASE YOUR
HEATED VISOR.



TO BE PRINTED ON A4



Shoei 004 Fitting Template



Cut out-side the line, Template perimeter

Arai 006 Fitting Template

- 1 PRINT OUT TEMPLATE ENSURING TO SET PRINTER TO "SCALE - ACTUAL SIZE".
- 2 CUT OUT THE VISOR TEMPLATE (OUTSIDE OF THE BLUE OUTLINE.).
- 3 PLACE ON THE VISOR WHERE REQUIRED TO CHECK THE FIT OF THE HEATED INSERT.
- 4 IF THE TEMPLATE FITS, HEAD OVER TO WWW.HEATEDVISOR.CO.UK AND PURCHASE YOUR HEATED VISOR.

TO BE PRINTED ON A4



Arai 006 Fitting Template



Cut out-side the line, Template perimeter